



Series HH7 Drive Assembly Exploded View Diagram



Series HH7 Drive Assembly Parts List

Key No.	Model Series	Part No.	Description	Qty.
1	HH711, HH721, HH731 HH718, HH728, HH738	48016	Control Panel Assembly, 115V	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	48017	Control Panel Assembly, 230-250V	1
	HH711, HH721, HH731 HH718, HH728, HH738	48071	EPU w/ Stroke Adjustment, 115V	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	48072	EPU w/ Stroke Adjustment, 230-250V	1
	HH711, HH721, HH731 HH718, HH728, HH738	48073	EPU, 115V	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	48074	EPU, 230-250V	1
	HH711, HH721, HH731 HH718, HH728, HH738	48075	Power Cord Assembly, 115V US, No Plug	1
2	HH711, HH721, HH731 HH718, HH728, HH738	37879	Foot	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	38199	Screw	3
	HH711, HH721, HH731 HH718, HH728, HH738	34497	O-Ring	1
	HH711, HH721, HH731 HH718, HH728, HH738	37734	Pulser, 120V	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	37735	Pulser, 230-250V	1
	HH711, HH721, HH731 HH718, HH728, HH738	10422	Retaining Ring	1
	HH711, HH721, HH731 HH718, HH728, HH738	35243	MOV and Capacitor Assy, 115V	1
3	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	35237	MOV and Capacitor Assy, 230-250V	1
	HH711, HH721, HH731 HH718, HH728, HH738	35743	Speed Shaft	1
	HH711, HH721, HH731 HH718, HH728, HH738	35744	Dual Pin	1
	HH711, HH721, HH731 HH718, HH728, HH738	30803	Gasket	1
	HH711, HH721, HH731 HH718, HH728, HH738	30709	Speed Knob	1
	HH711, HH721, HH731 HH718, HH728, HH738	38887	Gasket	1
	HH711, HH721, HH731 HH718, HH728, HH738	41244	Screw	1
130	HH711, HH721, HH731 HH718, HH728, HH738	35169	Stroke Dial	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	35166	Stroke Dial	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	35160	Stroke Dial	1
	HH711, HH721, HH731 HH718, HH728, HH738	31890	Stroke Knob Assembly	1
	HH711, HH721, HH731 HH718, HH728, HH738	37974	Cover	1
	HH711, HH721, HH731 HH718, HH728, HH738	10973	Seal	1
	HH711, HH721, HH731 HH718, HH728, HH738	38886	Stroke Adjustment Bracket	1
90	HH711, HH721, HH731 HH718, HH728, HH738	48012	Stroke Adjustment Shaft Assembly	1
	HH711, HH721, HH731 HH718, HH728, HH738	41227	Screw	8
	HH711, HH721, HH731 HH718, HH728, HH738	29033CE	Power Cord Assembly, 115V US	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	29039CE	Power Cord Assembly, 230V US	1
	HH712, HH722, HH732 HH713, HH723, HH733 HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	48076	Power Cord Assembly, 230V DIN	1
	HH715, HH725, HH735 HH716, HH726, HH736 HH717, HH727, HH737	48077	Power Cord Assembly, 240V UK	1
	HH716, HH726, HH736 HH717, HH727, HH737	29046CE	Power Cord Assembly, 250V AUST	1
HH717, HH727, HH737 HH718, HH728, HH738	29048CE	Power Cord Assembly, 230V SWISS	1	

Series HH7 Control Panel Detail



Series HH7 Wiring Diagram

