# LE-37 LIQUID HANDLING ASSEMBLY

For Series D
With 6.0 Liquifram

#### CAUTION

When pumping chemicals, make certain that all tubing is securely attached to the fittings. It is recommended that tubing or pipe lines be shielded to prevent possible injury in case of rupture or accidental damage. Always wear protective clothing when working on or near chemical metering pump.

#### MATERIALS OF CONSTRUCTION

Fittings Seal Rings 316 S.S. Teflon

Balls

316 S.S

Head

316 S.S

Liquifram

Teflon Face

Suction

1/2" NPT Male

Discharge

1/2" NPT Male

## A. INSTALLING INJECTION CHECK VALVE

- 1. The injection check valve should always be installed as close as possible to the point of chemical injection, at the very end of the piping run.
- 2. Purpose of injection check valve is to prevent backflow from *treated line* and to prevent syphoning or over pumping of chemical.
- 3. A 1/2" NPT female fitting with sufficient depth will accept the injection check valve.

#### **B. CONNECTING DISCHARGE PIPE**

NOTE: Corrosion resistant 1/2" Schedule 80 or Schedule 120 should be used. Do not use 1/4" pipe.

1. Discharge valve has 1/2" NPT male outlet. A 1/2" NPT union should be connected to both discharge and suction valves so that chemical metering pump may be removed without disturbing piping.

It is recommended that Teflon tape be used on tapered pipe threads so that there is a leakproof seal without overtightening of fittings.

#### C. CONNECTING SUCTION PIPE

- 1. Using the same size and material pipe as used on discharge line, cut suction pipe to required length.
- 2. Use of Teflon tape on tapered pipe threads is again highly recommended, to be sure connections are leakproof. Suction side leads are invisible but if a leak is present pump will suck in air during each suction stroke.
- 3. Maximum recommended vertical suction lift is 5 ft. (1.5m).

### D. PRIMING

- 1. Temporarily loosen the union on top of discharge valve.
- 2. Start pump and set pump at near maximum (80%) speed and 100% stroke.
- "D" series stroke cannot be adjusted until pump is operating electrically. Turn lower knob while unit is stroking.
- 3. As soon as chemical begins to leak at the union on top of discharge valve, stop the pump.
- 4. Pump is now primed.
- 5. Tighten union on top of discharge valve.



8 Post Office Square Acton, MA 01720 U.S.A. TEL (508) 263-9800 FAX (508) 264-9172

## NOTE:

Threaded connections into pump head are 1"-12 straight threads. **Do not use Teflon tape.** These joints are sealed by seal ring valve seats (item 5 on exploded view).

(0) (1) (1) (1)	PART NO.	DESCRIPTION	QTY.
1	27532	Head Assembly, LE-37	1
2	27530	Discharge Valve Assembly	1
3	26928	Valve Housing, 316 S.S., 1/2" NPT	1(2)
4	25042*	Ball, 316 S.S.	2(4)
5	25128*	Seal Ring, Teflon	2(4)
6	27395	Head, 316 S.S., 6.0SI	1
8	25719*	Liquifram, Teflon Face, 6.0Sl	1
9	27531	Suction Valve Assembly	1
10	26926	Valve Seat, 316 S.S., 1/2" NPT	1(2)
11	27534	Inj. Check/Back Pressure Valve Asm.**	(1)
12	26941	Injector Fitting**	(1)
13	10339*	Spring**	(1)
15	26951	Valve Seat, Foot**	(1)
16	27535	Foot Valve Assembly**	(1)
227 1820	10340	Screw, 10-24x3/4" PH S.S., NOT SHOWN	6



() Quantities with Optional Part No. 27534 & 27535

\*Parts included in Spare Parts Kit No. SP-37.

