

GLE-1- Ground Loop Interrupt Box

Product Instructions

1.0 - ELECTRODE AND GROUND INSTALLATION

STEP 1: Install electrode into GLE-1 via BNC connector marked "pH IN" as shown in FIG 1.

STEP 2: Install ground sensor into receptacle marked "GND IN" as shown in FIG. 1.

STEP 3: Install output cable into receptable marked "pH OUT" (opposite of inputs) as shown in FIG 2.

2.0 - BATTERY REPLACEMENT

STEP 1: Remove all connections from the GLE-1 first!

STEP 2: Turn GLE-1 upside down and remove 4 screws as shown in FIG 3.

STEP 3: Remove cover as shown in FIG 4.

STEP 4: Remove battery case as shown in FIG 5. (next page)

STEP 5: Remove all 4 batteries (AAA type) from battery case and replace with new ones as shown in FIG 6.

STEP 6: Reverse Steps 1-4 to reassemble the GLE-1

